

177304
JSD
GJONS

MICROSCOPE CARRIAGE INSTALLATION

CAUTION:

Micro switch actuator at rear of table in rail housing must be depressed when putting the microscope carriage on the rails.
If the switch actuator is not depressed it will be badly "mutilated."

1. Remove stops from left ends of rails.
2. Orient microscope carriage so that front of light table and front of microscope carriage correspond.
3. Slide microscope carriage on rails from left end of table.
4. Install stops removed in Step 1.
5. Slide film hold down glass between microscope carriage and film viewing surface such that the hinge on the glass is at the rear of the microscope carriage. Install clip and adjusting chain on front of film hold down glass.
handle
6. Install brake[^] on front of microscope carriage.

Declass Review by NIMA / DoD